


Sensor Activated Clean Dry™ Hand Dryer



| Item | Part | Description |
|------|------------|---------------------|
| 1 | THP3065 | Filter |
| 2 | THP3081#SV | Front Cover |
| 3 | THP3069 | Controller Assembly |
| 4 | THP3070 | LED |
| 5 | THP3071 | LED Harness |
| 6 | THP3072 | Motor Assembly |
| 7 | THP3073 | Thermistor |
| 8 | THP3074 | Baseplate |
| 9 | THP3075 | Gasket, Motor Cover |
| 10 | THP3076 | Gasket, Air Nozzle |

| Item | Part | Description |
|------|---------|------------------------------|
| 11 | THP3077 | Nozzle |
| 12 | THP3078 | Terminal Block, Power Supply |
| 13 | THP3079 | Under Cover Assembly, D. |
| 14 | THP3034 | Screw |
| 15 | THP3035 | Tapping Screw (DIA4X16) |
| 16 | THP3086 | Tapping Screw(DIA4X18) |
| 17 | THP3088 | M Screw (M4x12) |
| 18 | THP3036 | Tapping Screw (DIA4X16) |
| 19 | THP3052 | Hex Wrench/VAND/HDR |