


Touchless Soap Dispenser



Item	Part	Description
1	THP3567#CP	Spout
2	THP3161	Nut w/ Gaskets & Slip Washer
3	THP3162	Pump Unit
4	THP3163	Tank
5	THP3164	Battery Case
6	THP3271	AC Adapter
7	THP3140#CP	Escutcheon for 1-1/4"~1-1/2"(32~38mm) hole